

To save time and labour costs of a transmission repair substantially we worked out a method which makes it possible to speed up removing an engine unit without lifting off the platform as is has been required befor.

### Comparison of working time

Old method:		New method:
Removing complete engine	2.10 hours	not required
disconnect and connect engine-platform joints	included above	1.00 hour
complete platform dis-assembly and reassembly	4.00 hours	not required
Lift off platform partly only	-----	2.50 hours
Summit:	6.10 hours	3.50 hours

## Disassembly of gearbox without removing the platform

The additional with "a" shown points of this instructions concern vehicles with exhaust heating system.

Top of platform:

1. Remove both frontseats.
2. Engage four wheel drive.
3. Platform fastening: Remove all four bolts and put two 8 mm or 5/16" diameter bolts into both front holes to prevent platform from sliding off.
4. Loosen clutchcable at the steering box assy, pull off folding rubber hose.  
Push clutchcable back into conduite.

Engine:

1. Disconnect battery.
2. Take off upper part of blowercover.
3. Oilbath air filter: Remove two cylinder crews from carburettor, as well as screw at the preheating tube, open holding straps, take off snorkel and lift out filter.
4. Disconnect ignition cable and contact breaker wire.
5. Dynamo: Disconnect earth- plus- field wires, as well as starter wire and pull them out from tunnel of the air deflector plate.
6. Separate oil pressure switch wire at the connection terminal and pull out of cable-clip, the cable is to be left with the engine.

✓ Disconnect fuel line of fuel pump at the filter, at vehicles equipped with standard carburettor at the carburettor too.



## KUNDENDIENSTMITTEILUNG

**BETRIFT:** Working time of Haflinger transmission repair

Seite 51

Mitteilung 20

Datum September 1969

KD/KO/BR

8. Disconnect carburettor linkage and choke cable .
9. Take off engine mounts leave rear cover at the crossmember .
10. Take rubber plug out at the front side of the engine compartment, bend sheet metal underneath of the holes approximately 3 mm (1/8 of an inch) away to avoid platform to be hooked up on the threaded bolt of shock absorber mounts, while lifting it up.
11. Put disconnected wire ends out of the engine compartment on the platform.

## Underside

1. Remove sparewheel.
2. Front underguard: Remove four bolts from the rubber suspension.
3. Unhook hand brake linkage at the adjusting screw. After locknut is taken off, one person pulls hand brake lever fully, as a second man keeps holding the hand brake linkage in this position, whereupon the other person releases the hand brake lever again. By this means, removal of the adjusting nut is made easier. Loosen brake cable bracket from chassis. Unhook brake cable at the rear wheels pull it out of the mounts, leave it at the platform.
4. Rear underguard: Remove the two nuts from the flange of central and both rear securing bolts, take off underguard.
5. Rear thrust brace: pull out split pin, remove (crown) nut and cone.
6. Unhook linkage leading to the differential lock at the gearchange housing (pull out safety pin).
- 6a. Undo heater tube from the platform, pull both heater hoses from the muffler box. Disconnect mufflerbox on the rear attached to the lateral engine cover plate muffler stays with the engine. Lift platform up and secure it by placing a supporting base, approximately 150 mm (6 inches) high. (a piece of hardwood etc), between platform and cross member (see fig. 1).




fig. 1

Unterschrift  
z.Ktn.gen.









## KUNDENDIENSTMITTEILUNG

**BETRIFT:** Working time of Haflinger transmission repair

Seite 53

Mitteilung 20

Datum	September 1969
	KD/KO/BR

2. The crank handle or similar instrument can be used to hold the whole unit in horizontal position by one person, after sticking it into claws of the governor drive pulley (see fig. 4).
3. Two men should now move rear wheels back and forward until transmission gets loose from flange of central tube and can be taken out. It is not necessary to brace the central tube.




fig. 4

4. Connection sleeve to drive shaft should be marked, that side facing the transmission) by this means is a new alignment not necessary, when reassembling.
5. Take off lockring.

## Refitting the engine transmission

1. Spread gasket glue onto the surfaces, put gasketed on.
2. Thrust braces must be set the same height of the recess of crawler gear housing.
3. Shove complete unit back in again ( before that engage fourth or fifth gear).  
Lead clutch cable in, put thrust braces into the bracket. Bring clutch conduit into right position at the gear selector housing, while moving unit and frame together.
- 3a. At Haulers with exhaust heating the cable conduit as well as the brake lines must be lead underneath the connection of the heater boxes.
4. Tie up five nuts at the flange of central tube. Shove underguard over the lower two studs, put in bolts at the rear end of the shield and tie them up, first at the flange then at rear.
5. Put cones onto thrust braces, tie up crown nuts and lock with split pins.

Unterschrift  
z.Ktn.gen.



## KUNDENDIENSTMITTEILUNG

BETRIFFT:

## Working time of Haflinger transmission repair

Seite 54

Mitteilung 20

Datum September 1969  
KD/KO/BR

6. Connect brake lines at their junctions.
7. Fit differential lock linkage at the gear selector housing.
- 7a. Put a block, 150 mm (approx. 6 inches) high on the cross member, lower platform.
8. Adjust gear selecting system: turn three bolts into connection flange. One man keeps gear shift lever in right position (level 3<sup>rd</sup> and 4<sup>th</sup> resp. 4<sup>th</sup> and 5<sup>th</sup> gear), second person ties up the three bolts. Before that check if the selector shaft sits on lower stop (by turning the flange on transmission anticlockwise "seen from front". After bolts are tight check for correct working order of gear shifting system.
- 8a. Remove block from cross member.
9. Lower platform fully. Watch accelerator linkage and cables.
10. Tie up platform (Four bolts), mount seats.
11. Hook in hand brake cables at the rear wheels, tie bowden fastenings to the frame.
12. Connect hand brake linkage, to do so, one man pushes the brake shoes of the rear wheels forward, while the second man puts the adjusting nut onto linkage and sets hand brake. Brakes are working when hand brake lever is pulled back until it rests into fifth catch of rail. Tie up locknut next.
13. Push clutch cable forward and hook it in. Adjust clutch (dead travel at clutchpedal 20 mm, approx. 3/4 to 7/8 of an inch), slide connection sleeve over the both ends of cable conduit. Mount left side cover at the steering box mounting.
14. Bleed hydraulic brakes
- 14a. Mount heater tube.
15. Fit the lower four bolts into the front underguard.
16. Fill up transmission oil.
17. Fit spare wheel.

Engine compartment

1. Fit engine mounts and set sealing rubber.
2. Put in rubber plugs at the frontside of engine compartment.
3. Generator : Push starter - earth - plus and field wires through tunnel of air deflector plate.
4. Connect oil pressure switch wire.
5. Mount fuel line at the filter and carburettor.
6. Hook in accelerator linkage and choke cable and adjust it. The choke knob should move back 2 mm (approx. 3/32") when shoved back fully.
7. Connect ignition and contact breaker wire.

Unterschrift  
z. Ktn. gen.





## KUNDENDIENSTMITTEILUNG

Seite 55

Mitteilung 20

BETRIFFT: Working time of Haflinger transmission repair

Datum September 1969

KD/KO/BR

8. Assembly of airfilter and manifold: Put manifold onto carburettor, turn bolts 8 mm into tongue of preheattube, tie manifold first at carburetter then at heatertube. Turn lockingclips of oilbathairfilter tight and put on snorkel.
  - 8a. Mount mufflerbox to sidepanel of engineroom.
  9. Connect battery.
- Following checkup and testdrive.

Unterschrift  
z. Ktn. gen.