



Service Information

February 2023

Pinzgauer Split Boot Installation Guide

Background

- When installing split boots, please observe the following.
- The pinzgauer axle tube is elongated therefore the rubber boot is made such that the centre hole is not in line with the larger hole.
- The joint must therefore be installed as follows :
- Left side of vehicle – facing the front
- Right side of the vehicle – facing the rear
- They should NOT be installed with the joint facing upwards or downwards.
- Before bolting them together, smear a small amount of silicone sealant on the faces of the joint.
- Ensure all mating surfaces are clean and corrosion free.
- Failure to observe the above will reduce service life.



Haflinger Technik Ltd.

Roadmeetings Industrial Estate, Carlisle ML8 4QE

T 01555 751356

E parts@haflingertechnik.com

W www.haflingertechnik.com